





**Highly secure instant remote services** 





**SECURE CLOUD QUICK START GUIDE – JULY 2017 CLOUD CLIENT CONFIGURATION** 



#### **OVERVIEW**

The mGuard Secure Cloud offers secure, remote access worldwide in a simple to use format.

This quick start guide covers the basic configuration for one site

(Machine Connection) and one user (Technician Connection)

This is based on the entry level "BASIC EDITION" which allows one machine connection at a time with unlimited user and machine configurations. Further options are available just ask!



#### **CONTENTS**


- 1. INTRODUCTION TO THE MGURD SECURE CLOUD PAGE 3
  - 2. ACCOUNT REGISTRATION & LOGIN-PAGES 4-8
- 3. CREATING AN OPERTOR PROFILE (SERVICE WORKSTATION) PAGES 9-23
  - 4. CREATING AN OPERTOR PROFILE (MACHINES) PAGES 24-27
  - 5. CREATING THE MACHINE CONFIGURATION(LAN) PAGES 28-34
    - 6. UPLOAD THE CONFIGURATION PAGES 35-45
      - **7. TESTING PAGES 46-47**
  - 8. CREATING THE MACHINE CONFIGURATION(4G) PAGES 48-52
    - 9. TROUBLESHOOTING GUIDE PAGE 53-54



The mGuard Secure Cloud is managed by Phoenix Contact Cyber Security based in Berlin.

The hardware is maintained by a third party hosting centre to ensure 24/7 /365 day reliability.


The diagram below shows the standard topology used for standard remote access.






The first step is to get registered on the cloud. Go to https://uk.cloud.mguard.com

Click on "SIGN UP" and fill in your company details etc. as prompted



#### SECURE CLOUD QUICK START GUIDE - ACCOUNT REGISTRATION



#### Machine network


Please enter the destination network, which you want to reach through your VPN connection, for example, IP address of the network: 192.168.1.0 and Netmask: 255.255.255.0.

You will need to specify the network you will use at your target machine/s. This is essential for the Cloud to produce the correct configurations for your mGuard device and technician connections.



#### SECURE CLOUD QUICK START GUIDE - ACCOUNT REGISTRATION

You will need to accept the evaluation license agreement, enter the security code and then "OK"



Your registration is complete and in a short time you will receive a welcome e-mail containing several attachments:

- 1. The secure cloud user guide
- 2. User license agreement form
- 3. Price list for enhanced services

IMPORTANT – You must sign and return the license agreement form as instructed if you wish to continue using the cloud after the 30 day trial period.


Otherwise your account will be frozen after the 30 days expires.

There are no financial implications when signing this form. It is purely agreeing to the terms of use.



#### **SECURE CLOUD QUICK START GUIDE**


## Now you are registered "SIGN IN"






#### **SECURE CLOUD QUICK START GUIDE**

Use the account number provided in your welcome email and the user and password you used to create your account.






Select Service Workstations and click the +



The Service Workstation is necessary to create a secure VPN between the remote user and the cloud server to enable routing through to your chosen site configuration. Only one profile per user is required!!!!




Add the new operator name and press OK



© 2011-2016 PHOENIX CONTACT | Data privacy | Evaluation License Agreement | Legal Notice





**SECURE CLOUD QUICK START GUIDE – Creating an operator profile (SERVICE WORKSTATION)** 








## (SHREWSOFT VPN CLIENT)

Select the VPN client you wish to use - In this case we will select shrewsoft

Create a password and then click next



**QUICK START GUIDE -**

**Creating an operator profile (SERVICE WORKSTATION)** 


(SHREWSOFT VPN CLIENT)

**SECURE CLOUD** 





This is the IP address range you selected when you created the account – Then click REQUEST




SECURE CLOUD QUICK START GUIDE – Creating an operator profile (SERVICE WORKSTATION)

(SHREWSOFT VPN CLIENT)




Your user profile has been created - Download this to your PC ready to import to the shrewsoft VPN Client






(SHREWSOFT VPN CLIENT)

Go to the shrewsoft website and download the latest shrewsoft VPN client for your OS



# SECURE CLOUD QUICK START GUIDE – Creating an operator profile (SERVICE WORKSTATION) (SHREWSOFT VPN CLIENT)




Once installed open the shrewsoft VPN client.

Click on "FILE" and then "IMPORT"

Find the client configuration you created and downloaded on page 13.




(SHREWSOFT VPN CLIENT)



"IMPORT" this file.






Now click on \_\_\_\_\_\_ to initiate the VPN connection to the

CLOUD server. This creates a secure VPN from your PC to the CLOUD Server.




(SHREWSOFT VPN CLIENT)





(SHREWSOFT VPN CLIENT)




You will be prompted for your password. Enter your password and click on "OK"






#### (SHREWSOFT VPN CLIENT)



You will see as above "tunnel enabled"




#### (SHREWSOFT VPN CLIENT)



You have now connected to the CLOUD from your PC. You will see the icon turn green to indicate the connection and the connections that are active listed below.




(CLOUD CLIENT configuration)



Click on the Service Target (MACHINES) tab and then the slider below




(CLOUD CLIENT configuration)



Click on the add configuration icon




# (CLOUD CLIENT configuration)



Fill in your OPERATOR details as required. This creates the user profile/location for machine connections



## (CLOUD CLIENT configuration)




Now the user profile has been created. Click on the tab and begin to create your machine connection.



## SECURE CLOUD QUICK START GUIDE - Adding a new machine


(CLOUD CLIENT configuration)



Click on the add machine icon.




(CLOUD CLIENT configuration)



Fill in your machine details as required and then click "OK"



(CLOUD CLIENT configuration)




Click on the configuration wizard icon



# **SECURE CLOUD QUICK START GUIDE – Adding a new machine**

(CLOUD CLIENT configuration)




In this example we are using the TC CLOUD CLIENT LAN, assuming an internet connection is available on site.

THEN GO TO "NEXT"



# SECURE CLOUD QUICK START GUIDE - Adding a new machine

(CLOUD CLIENT configuration)



SELECT STATIC OR DHCP & TYPE IN THE IP ADDRESS OF THE CLOUD CLIENT IN YOUR MACHINE NETWORK

(MUST BE IN THE SAME RANGE AS THE MACHINE / SYSTEM YOU WISH TO REMOTELY CONNECT TO)

(ENTER THE DEFAULT GATEWAY IF KNOWN FOR STATIC CONNECTIONS)


THEN GO TO "NEXT"





# SECURE CLOUD QUICK START GUIDE - Adding a new machine

(CLOUD CLIENT configuration)




1- SELECT KEY SWITCH IF REQUIRED

2- ENTER A PASSWORD

3- REQUEST

(KEY SWITCH INPUT ENABLES OR DISABLES CONNECTION AT MACHINE)

# SECURE CLOUD QUICK START GUIDE – Adding a new machine (CLOUD CLIENT configuration)




NOW DOWNLOAD YOUR CONFIGURATION TO YOUR PC
(WHERE YOU CAN FIND IT)



(CLOUD CLIENT configuration) DOWNLOADING THE CONFIGURATION

NOTE 1 - MAKE SURE YOU CONNECT YOUR PC TO A LAN PORT

NOTE 2 - MAKE SURE ONE OF THE PORTS IS CONNECTED TO THE INTERNET ALSO (2 LAN PORTS)




#### ENTER THE DEFAULT IP OF THE CLOUD CLIENT

YOU MAY HAVE TO CHANGE THE IP OF YOUR PC TO DO THIS

(OPEN NETWORK AND SHARING CENTRE/LOCAL AREA CONNECTION/PROPERTIES/INTERNET PROTOCOL VERSION

4(TCP/IPV4)


Networking Sharing		
Connect using:		
Intel(R) 82579L	M Gigabit Network Con	nection
		Configure
This connection uses	the following items:	
✓   ■ Eset Persona	l Firewall	
☑ Packet QoS Packet	Scheduler	
☑ 🗐 File and Print	er Sharing for Microsoft	Networks
✓ - Internet Proto	ocol Version 6 (TCP/IPv	r6)
✓ → Internet Proto	ocol Version 4 (TCP/IPv	r4)  ≡
✓ - Link-Laver To	opology Discovery Map	per I/O Driver
	pology Discovery Resp	
4	""	
Install	Uninstall	Properties
Description		
Allows your comput	er to access resources	on a Microsoft
network.		





# SECURE CLOUD QUICK START GUIDE - Adding a new machine

(CLOUD CLIENT configuration)




YOU MAY SEE A SIMILAR MESSAGE TO THIS WHEN YOU TRY TO LOG ONTO YOUR CLOUD CLIENT SIMPLY CLICK ON ADVANCED AND "ADD EXCEPTION"






**(CLOUD CLIENT configuration)** 






(CLOUD CLIENT configuration)







**CLICK ON "SYSTEM"** 




(CLOUD CLIENT configuration)



**CLICK ON "LOAD CONFIGURATION"** 




(CLOUD CLIENT configuration)



CLICK ON "BROWSE" AND SELECT THE CONFIGURATION DOWNLOAD CREATED ON PAGE 33



(CLOUD CLIENT configuration)






### (CLOUD CLIENT configuration)




THE CONFIGURATION WILL LOAD WITHIN A FEW SECONDS THEN CLICK "REBOOT"






# SECURE CLOUD QUICK START GUIDE – Adding a new machine (CLOUD CLIENT configuration)



YOUR NEW CLOUD CLIENT IS NOW CONNECTED TO THE CLOUD
CONNECT YOUR VPN CLIENT AS IN PAGE 22 OF THE GUIDE AND YOU WILL HAVE A VPN CONNECTION



# FROM YOUR PC TO YOUR CLOUD CLEINT...NOW YOU CAN CONNECT YOUR MACHINE IN YOUR APPLICATION SECURE CLOUD TESTING




Log into your cloud account if you are not already and you will see the above image under the TAB

Service Targets (Machines)

Press Start and the cloud will create the complete connection between CLIENT & MACHINE






You will now see that the routing is complete and your remote connection is ready to use.

You must remain connected to the cloud to retain your remote access connection.

Use your machine software etc. as you normally would whilst connected. The VPN (Virtual Private Network) behaves like a cable replacement.




(CLOUD CLIENT 4G - configuration)



Select the TC CLOUD CLIENT 4G option
THEN GO TO "NEXT"



(CLOUD CLIENT 4G - configuration)



FILL IN THE APN SETTINGS FOR YOUR CHOSEN NETWROK PROVIDER (EE CONTRACT SHOWN IN EXAMPLE)

THEN GO TO "NEXT"



(CLOUD CLIENT 4G - configuration)




FILL IN THE IP ADDRESS YOU WANT FOR THE LAN PORT (IN THE SAME SUBNET AS YOUR MACHINE)

THEN GO TO "NEXT"



(CLOUD CLIENT 4G - configuration)



1- SELECT KEY SWITCH IF REQUIRED

2- ENTER A PASSWORD


3- REQUEST

(KEY SWITCH INPUT ENABLES OR DISABLES CONNECTION AT MACHINE)





(CLOUD CLIENT 4G - configuration)



NOW DOWNLOAD YOUR CONFIGURATION TO YOUR PC

(WHERE YOU CAN FIND IT)


THEN FOLLOW INSTRUCTIONS AS PER PAGES 35-47



### **SECURE CLOUD QUICK START GUIDE – Troubleshooting guide**


1. One of the most common issues is not being able to communicate via the mGuard Cloud using third party software (PLC/HMI programming software) This is due to the adapter settings created by the software that occupy the Ethernet port resource.

To solve this problem go into the "NETWORK & SHARING CENTRE"



## **SECURE CLOUD QUICK START GUIDE – Troubleshooting guide**

Now disable any network adapters that are not required (associated with third party software)



FOR ANY FURTHER SUPPORT ISSUES PLEASE CONTACT PHOENIX CONTACT UK CUSTOMER SERVICES

TEL: +00 44 (01952) 681700